

The water in the stormer inlets on my property wasn't flowing well, so I looked inside and I noticed it's cloqued with mud. What should I do?





## Remove all mud and blockages from your household stormwater inlets, and be sure to keep them clean.

Leaving your household stormwater inlets filled with dirt and mud may lead to hazardous blockages. Regularly check the condition of your inlets and clean them as needed.

Sweeping fallen leaves, snow, or other refuse into the stormwater inlets or sewage inlets will also lead to hazardous blockages, so refrain from doing so.



If a public stormwater inlet in the road (exempting private roads) has become clogged or no longer drains water efficiently, please contact that roadways management staff (for ward-owned roads, please contact the Ward Office).

Pouring highly volatile hazardous materials such as chemicals, gasoline, or paint thinners will cause the sewage pipes to melt or explode, leading to a disastrous accident. Do not under any circumstances pour those materials down the inlet.

\*Do not attempt to open public inlets under any circumstances.



If you're experiencing trouble with clogging on your property, please contact an Everything Drainage Consultation Center (p.25).